WARRANTY CARD

© 2015 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved. Distributed by Jarden Consumer Solutions of India Private Limited, Unit B-204, Universal Business Park, Off Saki Vihar Road, Chandivali Farm Road, Andheri (E) Mumbai 400 072, India. 2 Year Limited Warranty - see inside for details. Sunbeam Products, Inc. and Jarden Consumer Solutions of India Private Limited are subsidiaries of Jarden Corporation (NYSE: JAH).

1-800-102-6300

www.oster.in

Model No. : _____

Date of Purchase : _____

Dealer's Stamp : _____

P.N. 9100270000075
BVSTCG77B-049_15EM1
GCDS-OST38367-SL

Printed in PRC

MODEL **BVSTCG77B-049**

INSTRUCTION MANUAL

COFFEE GRINDER WITH CHAMBER MAID CLEANING SYSTEM

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

IMPORTANT SAFEGUARDS

To reduce the risk of fire, electric shock and/or injury to persons, basic safety precautions should always be followed when using electrical appliances, including the following:

1. **READ ALL INSTRUCTIONS BEFORE USING THE COFFEE GRINDER.**
2. Check if the voltage indicated on the appliance corresponding to the local mains voltage before you connect the appliance.
3. To protect against electric shock, do not put cord, plugs or motor base in water or any other liquids.
4. Close adult supervision is necessary when this appliance is used by or around children.
5. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
6. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
7. Unplug from outlet when Precision Coffee Grinder is not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning the appliance.
8. The use of accessory attachments that are not OSTER® brand may cause hazards or injuries.
9. Do not use outdoors.
10. Do not let cord hang over edge of table or counter, or touch hot surfaces.
11. Do not place this appliance on or near a hot gas or electric burner or in a heated oven.
12. To disconnect, turn unit off, then remove plug from wall outlet.
13. Do not use appliance for other than its intended use.
14. Use on a hard, flat level surface only, to avoid interruption of air flow underneath the appliance.
15. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
16. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

THIS UNIT IS FOR HOUSEHOLD USE ONLY.

WARNING! To reduce the risk of fire or electric shock, do not remove any service covers. There are no user serviceable parts inside the coffee grinder. Only authorized personnel should repair the appliance. Opening the bottom service cover will void the warranty.

DO NOT USE THIS COFFEE GRINDER TO GRIND ANY INGREDIENTS OTHER THAN COFFEE BEANS.

Please read ALL of the instructions in this manual carefully before you begin to use this appliance. Proper care and maintenance will ensure a long life and a trouble-free operation for this appliance. Please save these instructions and refer to them for cleaning and care tips.

SAVE THESE INSTRUCTIONS

Introduction

Thank you for selecting the OSTER® Coffee Grinder with Chamber Maid Cleaning System, a highly innovative and ergonomically designed, state-of-the-art coffee grinder. Your unit can grind whole coffee beans to brew up to 12 cups of coffee.

It has setting indicator lights, an auto off timer, variable grind settings - from fine to coarse, a dishwasher-safe, fully removable grinding chamber which includes a no-spill, flip-open lid for easy pouring and filling and a self-cleaning upper collar with integrated Chamber Maid bowl scrapers, plus discreet cord storage.

Your new OSTER® Coffee Grinder with Chamber Maid Cleaning System lets you enjoy the freshest cup of coffee ever.

BVSTCG77B-049_15EM1.indd 2-3 3/11/15 10:24 AM

DIAGRAM OF PARTS



1 Flip Open Lid
2 Cap Assembly
3 Chamber Maid Cleaning System
4 Removable Grinding Chamber
5 Base
6 Cord Storage
7 Grind Setting button and Indicator Light
8 Cup Selector and Indicator Light
9 Start Button
10 Finger Tab

CLEANING AND PREPARING YOUR OSTER® PRECISION COFFEE GRINDER FOR USE

Before using your Coffee Grinder for the first time, clean it according to the following instructions. Then, to ensure optimal Coffee Grinder function and durability, clean it regularly following these simple steps.

1. Always make sure your Coffee Grinder is unplugged before cleaning and after use.

2. Remove the Removable Grinding Chamber from the Base by rotating it counterclockwise until it stops, then lift it straight up (Figure 1).

3. Now rotate the Cap Assembly counterclockwise a full 180 degrees (a full half circle) until it stops.

4. Lift the Cap Assembly straight up (Figure 2).

5. Wash Grinding Chamber components with mild detergent and water. You may also wash them in your dishwasher's top rack.

WARNING! Do not put Base in dishwasher. Care shall be taken during cleaning the Grinding Chamber, beware of the sharp cutting blade.

6. Once both components are clean, make sure they are completely dry before reinstalling them in the Coffee Grinder.

7. Align the arrow on the cap spout with the cap unlock symbol (🔓) on the Grinding Chamber and insert.

8. Rotate the Cap Assembly clockwise until the cap stops (Figure 3).

9. Reinsert the Grinding Chamber into the Grinder Base and rotate clockwise until it stops. Be sure the cap spout arrow is aligned with the cap lock (🔒) symbol on the front of the unit (Figure 4).

Figure 1

Figure 2

Figure 3



Figure 4

BVSTCG77B-049_15EM1.indd 4-5 3/11/15 10:24 AM

USING YOUR OSTER® PRECISION COFFEE GRINDER

The OSTER® Coffee Grinder with Chamber Maid Cleaning System features 3 grind settings, from fine to coarse. The Coffee Grinder uses specialized blades to chop the whole beans to a uniform grind, releasing the unique flavour and aroma of your favorite coffee. To use:

Figure 5

1. Make sure the unit is clean as per the instructions in “Cleaning and Preparing Your OSTER® Precision Coffee Grinder for Use”.

2. Open the Flip Open Lid and fill the Grinding Chamber with fresh coffee beans, according to the Coffee Measurement Chart (Figure 5).

COFFEE MEASUREMENT CHART

For Automatic Drip coffeemakers, use the medium grind setting, fine for espresso and coarse for French Press coffeemakers. For best results, do not grind more than 12 tbsp. of coffee at a time.

To Brew	Ground Coffee
12 Cups	9 Tbsp.
10 Cups	7.5 Tbsp.
8 Cups	6.5 Tbsp.
6 Cups	4.5 Tbsp.
4 Cups	3 Tbsp.

1 level tablespoon (tbsp) = 5 gr.
1 cup = 148ml. of brewed coffee
Use more or less coffee to suit your taste.



Figure 6

3. Close the lid.

4. Plug in the unit.

5. Press the Grind Setting Button until the indicator light shows your preferred grind setting (Figure 6).

Figure 7

6. Select the number of cups of coffee you will be brewing with the Cup Selector, from 4 to 12 cups (Figure 7). To obtain the best cup of coffee or espresso, grind only the amount of coffee beans you will use immediately.

7. Press and hold the Start Button (Figure 8) until the timed grinding cycle is complete, about 15 seconds for 12 cups.

Figure 8

8. When grinding is complete, remove the Grinding Chamber from the Base by rotating it counterclockwise until it stops, then lift it straight up.

9. Use the Chamber Maid feature by twisting the cap back and forth to remove the coffee grounds from the sides of the Grinding Chamber (Figure 9).

Figure 9

10. Gently lift the Chamber Lid using the convenient Finger Tab.

11. Gently shake the coffee grounds into your coffee brewer (Figure 10).

12. Replace the Grinding Chamber in its Base.



Figure 10

NOTE: When unplugged, the Coffee Grinder will revert to its default setting to grind coffee beans for 12 cups of coffee using a medium grind. Care shall be taken during emptying the Grinding Chamber, beware of the sharp cutting blade.

HELPFUL GRINDING HINTS

You may customize the bean quantity recommendations presented as you familiarize yourself with your new OSTER® Coffee Grinder, but always bear in mind the following:

1. Use medium grind (⬬) for automatic drip coffee makers, fine (⬬) for espresso and coarse (⬬) for French press.

2. Using fine grounds for brewing coffee in automatic drip coffee makers might cause an overflow of the paper filter and/or the brew basket. Also, the taste of the coffee might be stronger than desired.

3. Using coarse grounds for brewing coffee in an automatic drip coffee maker might cause the taste of the coffee to be weaker than desired.

4. To brew espresso or cappuccino, grind the amount of coffee grounds recommended by your product manufacturer.

   a. For OSTER® Espresso products:

      1) Set the coffee grinder to Fine grind and 4 cups.

      2) Use the chart on page 5 for recommended amount of coffee rounds.

   b. Using improper medium or coarse coffee grinding settings might affect the taste of the brewed espresso coffee, because the optimum coffee extraction is not achieved using the coarse grind setting.

5. If a coarser setting is required to brew coffee manually, in a percolator or using a French press, grind the amount of coffee grounds recommended by your product manufacturer using the coarse grind setting.

6. Remember, you can customize the recommendations above as you discover which settings best meet your personal coffee-making preference.

BVSTCG77B-049_15EM1.indd 6-7 3/11/15 10:24 AM

FOR BEST RESULTS

1. Use only coffee beans in this unit, do not grind nuts or spices.
2. Do not store coffee beans in the Grinding Chamber.
3. Do not use the finest setting when grinding coffee for your automatic drip coffeemaker. The finer grounds could cause the coffee basket to overflow.
4. To avoid overheating the motor, do not grind more than 2 full 12-cup cycles without a break. Allow the motor to cool at least 5 minutes between cycles.
5. Flavored coffee beans may gum up the blades and leave an oily residue on them. Be sure to clean your Coffee Grinder more frequently when using flavored beans and to clean all caked-on coffee particles from your Coffee Grinder during cleaning.
6. Clean unit after every use for best performance.

TROUBLESHOOTING YOUR OSTER® PRECISION COFFEE GRINDER

Your OSTER® Coffee Grinder with Chamber Maid Cleaning System has been carefully designed to give you many years of trouble-free service. In the unlikely event that your new coffee grinder does not operate satisfactorily, please review the following potential problems and try the steps recommended BEFORE you call an Authorized Service Center.

PROBLEM	POSSIBLE CAUSE	SOLUTION
UNIT DOES NOT GRIND	Grinding chamber lid is open.	CLOSE GRINDING CHAMBER LID.
	Grinding chamber is not in position.	PLACE CHAMBER IN PROPER POSITION.
	Start Lever has not been pressed.	PRESS AND HOLD START LEVER.
	Unit is unplugged.	PLUG UNIT IN.
	There's a power outage.	WAIT FOR POWER TO BE RESTORED.
	If after trying all of the above the unit still does not grind, the motor has overheated, thermal fuse is broken.	CALL AUTHORIZED SUNBEAM SERVICE CENTER.
THE COFFEE GRINDS PRODUCED ARE NOT PROPERLY GROUND	Grind setting or cups setting is incorrect.	SET GRIND SETTING OR CUPS SETTING CORRECTLY.
	Insufficient amount of whole beans used.	ADD BEANS TO GRINDING CHAMBER. PLEASE DO NOT EXCEED MAXIMUM CAPACITY OF 12 TBSP.
	Chamber lid opened during operation.	CLOSE GRINDING CHAMBER LID.
	Unit is not clean.	UNPLUG UNIT, CLEAN IT AS PER INSTRUCTIONS AND PLUG IT IN AGAIN.
	Foreign object is obstructing the grinder blades.	UNPLUG UNIT AND CAREFULLY DISLODGE FOREIGN OBJECT.
UNIT STOPS GRINDING	Grinding chamber lid has been opened.	CLOSE GRINDING CHAMBER LID.
	Unit has been unplugged.	PLUG UNIT IN.
	There's a power outage.	WAIT FOR POWER TO BE RESTORED.

Do you still have questions? You can call us at the Consumer Service number as shown on the back cover, or you can visit us at www.oster.in.

SERVICE AND MAINTENANCE

If your Coffee Grinder requires service, do not return it to the store where you purchased it. All repairs and replacements must be made by an authorized Service Center in India. See following pages for the authorized service centers.

BVSTCG77B-049_15EM1.indd 8-9 3/11/15 10:24 AM

WARRANTY

Jarden Consumer Solutions of India Private Limited (hereinafter referred to as "JCS") warrants that, for a period of two (2) years from the date of purchase of this product as evidenced in the cash memo ("Warranty Period"), this product will be free from defects in material and workmanship (the "Warranty"). Please preserve the warranty card and the cash memo of the product duly stamped and signed by the dealer, as this will be required for any claims under this Warranty.

- The rights and benefits under this Warranty are additional to your statutory rights, which are not affected by this Warranty.
- During the Warranty Period, JCS, at its sole choice, will either repair or replace this product or any component of the product found to be defective free of cost through (the dealer from whom the product was purchased or through the service center listed in the card – business people to confirm), provided that:
  - JCS is promptly informed of the defect;
  - The product has not been altered in any way or subjected to misuse or repair by the person other than a person authorized by JCS;
  - This Warranty, duly filled, stamped and signed by the dealer is made available.
- The Warranty provided herein is towards the original purchaser and is not transferrable to any third party.
- Any repaired or replaced product will be warranted on these terms for the remaining portion of the Warranty in the country where the product was purchased.
- Liability for consequential loss or damage is neither accepted nor is it implied.
- This Warranty is in lieu of all others expressed or implied and does not cover the following:
  a. If product was use in any manner other than the intended use.
  b. If the product has not been used according to the instruction manual/user's manual, included with the product.
  c. If the defects are caused by improper use or reckless use.
  d. If the product was altered or repaired by anyone other than those authorized by JCS.
  e. If installation of the product is not done as per the printed instructions provided along with the product.
  f. If the defects are caused by fire, flood, and other act of god.
  g. If the defects are caused by use of incorrect current or voltage or faulty electric power supply.
  h. Normal wear and tear of parts and accessories resulting from regular use.
  i. Damage resulting from transportation, accidents, mishandling or negligence on the part of the consumer.
  j. The following part/components:
    - Broken glass or ceramic parts
    - Light bulb
    - Accessories
  k. If the product is put to industrial or commercial use.
  - JCS will not be responsible for any delay in servicing due to non-availability of any components or due to reasons beyond the control of JCS.
  - Any failure of the product to perform any purpose other than the intended purpose shall not be considered as a default under this warranty.
  - In any event, if JCS becomes liable for damages incurred in connection with these presents, then the liability of JCS will be limited to the amount equal to the sale invoice amount paid by you.

Waste electrical products should not be disposed off with household waste. Please recycle where facilities exist.

AUTHORIZED SERVICE CENTERS

Region	State	City	Name	Address	Contact Person	Contact No.
East	West Bengal	Kolkata	Jeeves Consumer Services Pvt Ltd	356, Jodhpur Park, Kolkata - 700068	Someswar Basu	(033) 40012100
	West Bengal	Kolkata	Southern Service	6/19A, Prince Anwarshah Road, Poddar Nagar, Kolkata - 700068	Subrata Manna	(033) 24729651 / 65488822
	West Bengal	Kolkata	Baishanu Service Care	55D, Adaya Nath Saha Road, Lake Town, Near Jaya Cinema, Kolkata - 700048	Piyush Nandan	(033) 40664210
	West Bengal	Howrah	Time n Service	37 & 38, Mohenath Lane, Salkia, Howrah - 711106	Tapas Hazra	(033) 65639720
	West Bengal	Hooghly	DNP Enterprises	52, Sahaganj Main Road, PO. Sahaganj, Near Bandel Station, Hooghly - 712104	Indrajit Bag	(0) 9163668360
	West Bengal	Barrackpore	Balaji Enterprise	4/E/A Barasat Road, Barrackpore, Dist. North 24 Parganas, Near 15 No. Rail Gate, Barrackpore - 700122	Pradip Kr Ghosh	(033) 25451224
	West Bengal	Siliguri	S D Electronics	Deys Lodge,138/69/57, Nazrul Sarani, Ashrampara, Siliguri - 734001	Arup Dey	(0353) 2526028
	West Bengal	Asanol	Yes Service	Hutton Road, Near Mahal Banquet Marriage Hall, Asansol - 713301	Sarfaraz Ahmed	(03228) 2280029
	Assam	Guwahati	Multi Track Services	G S Road, Ground Floor, Bora Service Station, Ulubari, Guwahati - 781007	Kallol Dutta	(0361) 2457296

BVSTCG77B-049_15EM1.indd 10-11 3/11/15 10:24 AM

AUTHORIZED SERVICE CENTERS

North	Delhi	Delhi	Jeeves Consumer Services Pvt Ltd.	# E-10, Arya Samaj Road, School Road, Uttam Nagar, Delhi - 1100059	Md Khalid Pervez	(011) 45785915
	Delhi	Delhi	Jeeves Consumer Services Pvt Ltd.	R-32, 2nd Floor, Vikas Marg, Shakarpur, Opp. Heera Sweets, Metro Pillar # 46 , Delhi - 1100092	Manjeet Singh	(011) 47754764
	Delhi	Delhi	S T Services	M-131, 1st Floor, Guru Harkrishan Nagar, Paschim Vihar, New Delhi - 110041	Vipin Yadav	(011) 32958438 / 45586987
	Haryana	Gurgaon	Jeeves Consumer Services Pvt Ltd.	4/18 A, 1st Floor, Laxmi Garden, Behind Police Chowki, Khandsa Road, Gurgaon-122001	Karamvir Fogaat	(0124) 4073434
	Haryana	Faridabad	Jeeves Consumer Services Pvt Ltd.	5H-49,1st Floor, NIT Faridabad -121001	Manoj Kumar Panwar	(0129) 4163003
	Uttar Pradesh	Noida	Jeeves Consumer Services Pvt Ltd.	1st Floor, Above Punjab ATM, Sector-22, Chaura More Main Road, Near Oriental Bank of Commerce, Opp.Rajkiya Inter College, Noida, U.P - 201301	Devender Singh	(0120) 4162644
	Uttar Pradesh	Lucknow	Swastik Customer Care	A-1/3, SEC-H Aliganj, Near Kendriya Bhawan, Lucknow - 226020	Uma Shankar Mishra	(0522) 3298003 / 4102581 / 4102582
	Uttar Pradesh	Kanpur	Shubham Electronics	192,Manohar Nagar Barra -3 , Opp Deepshika Guest House, Kanpur - 208027	Suman Gupta	(0512) 2283394 / 2602029
	Uttar Pradesh	Agra	Sai Electronics	25/113, Gandhi Nagar, Agra - 282 003	Ajay Singhal / Sunil	(0562) 3297005
	Haryana	Ambala	Telecare	Old Hospital Road, Bara Thakur Dwara, Opp. Polytechnic, Ambala City - 134003	Devinder Sharma	(0171) 25567369
	Haryana	Sonipat	Saibaba Enterprises	House No. 1510, Sector - 15, Sonipat - 131001	Pramod Sharma	(0130) 6411206
	Haryana	Karnal	Jeeves Consumer Services Pvt Ltd.	Shop # 50, Ground Floor, Mayapuri, Rajiv Gandhi Marg/ Near Raj Palace, Meeraghati Chowk, Karnal - 132001	Neeraj Sharma	(0184) 4022201
	Punjab	Mohali	Jeeves Consumer Services Pvt Ltd.	# SCF-4, Basement, The High Land Society, NAV, Baltana, Zirakhpur, Mohali-140603	Shiv Dhanda	(0176) 2652574
	Punjab	Ludhiana	Jeeves Consumer Services Pvt Ltd.	Shop # 18B, Dhyan Singh Commercial Complex, Opp. Bus Stand, Ludhiana - 141001	Gurbeer Singh	(0161) 2444002
	Punjab	Jallandhar	Jeeves Consumer Services Pvt Ltd.	EH-31, Laddowali Road, Opposite Gurudwara, Jalandhar - 144001	Ashok Kumar	(0181) 2221707
	Punjab	Amritsar	Keerat Electronics	Naraingarh Bazar, Shaheed Bhagat Singh Road, Chheharta, Amritsar - 143 001	Sukhdeep / Mantreet Singh	(0183) 2450095
	Himachal	Shimla	Suvidha Electronics	Mehta Niwas, Ground Floor, Near Himfead Building, B C S, New Shimla - 171009	Rajesh Kumar	(0) 9816457886
	Himachal	Mandi	Kuldeep Electro Care	Neear FCI Godown, Kehanwal Road, Ram Nagar, Mandi - 175001	Kuldeep Singh	(01905) 222140 / 329574
	Rajasthan	Jaipur	Jeeves Consumer Services Pvt Ltd.	A-79,Subash Nagar Shopping Centre, Jaipur - 302016	Vipendra Singh	(0141) 4035102

AUTHORIZED SERVICE CENTERS

West	Maharashtra	Mumbai	S P Services	Shop No. 10, Abdul Sattar Compound, Fitwala Road, Opp. Satguru Darshan Bldg., Near Railway Station, Elphinston Road (West), Mumbai - 400013	Palsingh Panyari	(022) 24326726 / 24312623
	Maharashtra	Mumbai	Jeeves Consumer Services Pvt Ltd.	Plot No 27/5, Pawani Chowk, Opp Mulund Darshan Building, Mulund Colony, Mulund (W), Mumbai - 400082	Ramesh Yadav	(022) 65288597
	Maharashtra	Mumbai	Jeeves Consumer Services Pvt Ltd.	Shop No.1-1A, Ground floor, Kirti Co-Op Housing Society, Ramachandra Extn Lane, Near Movie Time, Evershine Nagar, Malad(W), Mumbai-400064	Murali Joshi	(022) 65278590
	Maharashtra	Pune	Jeeves Consumer Services Pvt Ltd.	No. 337, Sai Leela, 1st Floor, Datt Wadi, Mhasoba Chowk, Pune - 411030	Saket Dubey	(020) 24321679
	Maharashtra	Nagpur	Technic Services	Khare Building, Hanuman Lane, Sitabuildi, Nagpur - 440 012	Dilip Panda	(0712) 2550076
	Maharashtra	Chandrapur	Suvidha Electronics	No. 1, Devt Appartment, Church Road, Hanuman Nagartukum, Chandrapur - 442401	Subash Deashkar	(07172) 258966 / 256453
	Maharashtra	Kolhapur	Sikir Mobiles	1492 C Ward, Laxmipuri, Opp. TATA Brand Stores, Kolhapur - 416001	Sukir Bakare	(0) 9372555011
	Maharashtra	Aurangabad	Emperor Services	S-5,Manik Arcade Kalda Corner, Opp Chowbey Hospital, Chetna Nagar, Aurangabad -31005	Mr. Willy Bento Colaco	(0240) 2350606
	Maharashtra	Nashik	Harsha Electronics	3, Talak Complex, Rachna Vidyalaya Road, Sharanpur Roda, Nashik - 422002	Pravin Patil	(0) 9422254240
	Goa	Salcete	Jolly Enterprises	Shop # G-2, 78/A Nuvem Enclave, Along NH-17 Highway, Belloy Nuvem, Salcete - 403604	John Gonzanalves	(0832)2791800
	Gujarat	Ahmedabad	Jeeves Consumer Services Pvt Ltd.	No. 37, Om Tower, Near Star Bazar, Jodhpur Cross Road, Satellite, Ahmedabad - 380015	Girish Parmar	(079) 40080485
	Gujarat	Baroda	Uday Refrigeration	G/3 Nandanvan Comples, Atma Jyoti Ashram Road, Behind Citizen Society, Ellora Park, Baroda	Shailesh	(0265) 6590948
	Gujarat	Surat	Sadgurudev	Shop No. L/6, Shankutal Complex, Beside Sangvi Tower, Near Gujarat Gas Circle, Adajan Patia, Surat - 395009	Manoj Rana	(0261) 6540417
	Gujarat	Rajkot	PC Systems	4-Sardar Nagar (West),Tagore Road, Near Astron Circle, Rajkot-360001	Manoj Gohil	(0281) 2480479
	Madhya Pradesh	Indore	Cool Home Refrigeration	LG-70, Trade Centre, 18, South Tukogunj, Indore- 452 001	Husain Anjum	(0731) 4076404
	Madhya Pradesh	Bhopal	Jeeves Consumer Services Pvt Ltd.	Ward no 47, Goyal Vihar, Ground floor, Flat no-G-1, 31-C, Zone-2, MP Nagar, Bhopal	Ram Ashish Prasad	(0755) 4059310

BVSTCG77B-049_15EM1.indd 12-13 3/11/15 10:24 AM

AUTHORIZED SERVICE CENTERS

South	Tamil Nadu	Chennai	Jeeves Consumer Services Pvt Ltd.	New No.3,Old No.1-A, Sripuram,2nd Lane,Royapetah, Chennai-600014	Dinesh Kumar	044-42632371
	Tamil Nadu	Chennai	G C Services	Old No. 12, New No. 37, 1st Floor, Sattanna Naichen Street, Nehru Timber Market, Choolai, Chennai - 600112	Naval R	(044) 26690084 / 42822868
	Tamil Nadu	Coimbatore	V K Engineering	108-A/92, West Ponnurangam Road, Ground Floor (Near Telephone Exchange), R.S.Puram, Coimbatore - 641002	Selvadurai	(0422) 2541172
	Pondicherry	Pondicherry	Bestronics	49, Saint Theresa Street, Pondicherry - 605001	B Jayashankar	(0) 9443728020
	Andhra Pradesh	Hyderabad	Jeeves Consumer Services Pvt Ltd.	Flat No. 205, Karan Centre, Opp. IBP Petrol Pump and Karan Hotel, Park Lane, S.D.Road, Near Paradise Circle, Secunderabad - 500003	Kumararajan	(040) 64591168
	Andhra Pradesh	Vijaywada	Jeeves Consumer Services Pvt Ltd.	Door No.25-10-10A,G.S.Raju Road,Gandhi Nagar, Near Gymkhana Road, Vijayawada - 520003	Rahamatullah Gouse Khan	(0866) 6591168
	Karnataka	Bangalore	Jeeves Consumer Services Pvt Ltd.	No. 126, 1st Floor, 8th Main J.P.Nagar, 3rd Phase, Bangalore - 560078	Ramesh Kumar	(080) 41209331
	Karnataka	Bangalore	Jeeves Consumer Services Pvt Ltd.	First Floor, Khan Bldg, 7 & 8th Cross, Jakkasandra Extension, Bangalore - 560032	Surulivel	(080) 25520424
	Karnataka	Mangalore	Jeeves Consumer Services Pvt Ltd.	1st Floor, Quadra compound, Bejai,kapikad, Kavoor Road, Mangalore -575004	Divakar Shetty	(0824) 2213699
	Karnataka	Mysore	Jeeves Consumer Services Pvt Ltd.	No.1095, 1st Floor, C&D Block, Lalithadri Road, Kuvempunagar, Mysore - 570023	Venkatesh.S.Kulkarni	(0821) 4191094

BVSTCG77B-049_15EM1.indd 14-15 3/11/15 10:24 AM